

VX219A toycod&beyourlover

Before Use

Please fully charge our product before the first use. The charging time is about 2 hours, after it's fully charged, the LED light will stay on.

Please remove piercings or jewelry in the nipple, genital, and other areas before use. Be sure to clean and disinfect the product before use. If you want to use a lubricant please adequately lubricate the product and your private parts with a water-based lubricant.

Product Specification

Product Name: BOBO

Product No.: VX219A

Material: Silicone, ABS

Size: 123*37*37mm

Weight: 30g±3g

Battery Type: Polymer lithium battery

Battery Capacity: 230mAh

Rated Voltage: 5V

Charging Current: 500mA

Charging Time: ≤2 hours

Working Time: ≥1 hours

Vibration Mode: 10

Waterproof Rating: IPX4

Button Display



DC Charging Port




Power & Function Button

How to Use

Power (On/Off)

Press the button “” for 1.5s to turn on/off the power.

Vibration Mode

With the device powered on, single-press the “” button to switch between 10 vibration modes. The lollipop-shaped design with a bow can also be used as an intimate massage pen.

LED Display

Working	LED remains on
Low battery	LED flashes
Charging	LED flashes
Fully Charged	LED remains on

Usage Instructions

Before using this product, please read this instruction manual thoroughly and understand the usage precautions, product features, and methods to ensure correct and safe use. Additionally, keep this manual in a safe place for future reference.

- Clean the product thoroughly before use with a water-based lubricant.
- If not used for a long time, clean it well and store it away from direct sunlight, high temperatures, and high humidity.

Charging

- Always use a standard charging AC adapter and the included charging cable. The fast-charging adapter may cause the built-in battery to deteriorate or fail to charge fully.
- Make sure the connection part does not get wet during charging.
- Ensure the charging time does not exceed 12 hours and monitor the charging process closely.
- Do not use the product while charging.

Maintenance

This product complies with the international waterproof standard. Do not immerse it in water, as this may cause malfunction. After cleaning, wipe off any moisture and allow it to dry completely.

- If not used for a long time, store it away from high humidity and direct sunlight.
- Before the first time or after a long period of non-use, make sure to charge it once fully.

Warning

- As this is an adult product, keep it out of reach of children.
- If you experience skin allergies or discomfort while using the product, stop using it immediately and consult a doctor if necessary.
- If you find any malfunction or abnormal behavior, stop using it immediately and turn off the power.

Disposal

- This product contains a lithium-polymer battery. Do not dispose of it as household waste. When disposing, remove the battery and follow the disposal methods prescribed by your local authorities.