



BEYOURLOVER
ビュアラバー



Angela (アンジェラ)

取扱説明書

Before Use

Please fully charge our product before the first use. The charging time is about 2.5 hours, after it's fully charged, the LED light will stay on.

Please remove piercings or jewelry in the nipple, genital, and other areas before use. Be sure to clean and disinfect the product before use. If you want to use a lubricant please adequately lubricate the product and your private parts with a water-based lubricant.

Product Specification

Product Name: Angela

Product No.: VX603A

Material: Silicone, ABS

Size: 218*86.5*38.5mm

Weight: 225g±5g

Battery Type: Polymer lithium battery

Battery Capacity: 900mAh

Rated Voltage: 3.7V

Rated Current: 900mA

Charging Time: ≤2.5H

Working Time: ≥50Min



Vibration Mode: 8

Suction Mode: 10

Tapping Mode: 7

Water repellency: IPX6

Button Display



Magnetic Charging Port



Vibration Button



Suction Button



Tapping Button

How to Use

Vibration Mode

Press the button "  " for 1.5s to turn on/off the vibration mode.

Click the button "  " to switch 8 different vibration modes.

Suction Mode

Press the button "  " for 1.5s to turn on/off the suction mode.

Click the button "  " to switch 10 different suction modes.

Tapping Mode

Press the button "  " for 1.5s to turn on/off the tapping mode.

Click the button "  " to switch 7 different tapping modes.

APP Remote Control

Turn on your phone's Bluetooth and connect the product to the official APP for remote control. (The APP can be downloaded by scanning the QR code attached)

LED Display

Working	LED remains on
Low battery	LED flashes
Charging	LED flashes
Fully Charged	LED remains on

Usage Instructions

Before using this product, please read this instruction manual thoroughly and understand the usage precautions, product features, and methods to ensure correct and safe use. Additionally, keep this manual in a safe place for future reference.

- Clean the product thoroughly before use with a water-based lubricant.
- If not used for a long time, clean it well and store it away from direct sunlight, high temperatures, and high humidity.

Charging

- Always use a standard charging AC adapter and the included charging cable. The fast-charging adapter may cause the built-in battery to deteriorate or fail to fully charge.
- Make sure the connection part does not get wet during charging.
- Ensure the charging time does not exceed 12 hours and monitor the charging process closely.
- Do not use the product while charging.

Maintenance

This product complies with the IPX6 international waterproof standard and can withstand high-pressure water flow from any angle.

Submerging it in water may cause malfunction. Wipe off any moisture and dry it completely after rinsing.

- If not used for a long time, store it in a place away from high humidity and direct sunlight.
- Before the first time or after a long period of non-use, make sure to fully charge it once.

Warning

- As this is an adult product, keep it out of reach of children.
- If you experience skin allergies or discomfort while using the product, stop using it immediately and consult a doctor if necessary.
- If you find any malfunction or abnormal behavior, stop using it immediately and turn off the power.

Disposal

- This product contains a lithium-polymer battery. Do not dispose of it as household waste. When disposing, remove the battery and follow the disposal methods prescribed by your local authorities.

使用前


初めてお使いになる際は必ずフル充電を行ってからご使用ください。充電時間は約2.5時間で、フル充電するとLEDランプが点灯します。

本製品を使用する前には、乳首や性器などのピアスやアクセサリを取り外して、本製品を洗浄・消毒してからご使用ください。ローションを使用する場合は、水溶性ローションで製品とプライベートパーツをよく潤滑してください。

製品仕様

商品名: Angela(アンジェラ)	定格電流: 900mA
型番: VX603A	充電時間: 2.5時間
材質: シリコン、ABS	稼働時間: 50分
サイズ: 218*86.5*38.5mm	振動モード: 8種類
重量: 225g±5g	吸引モード: 10種類
電池種類: リチウムポリマー電池	タッピングモード: 7種類
電池容量: 900mAh	防水レベル: IPX6
定格電圧: 3.7V	


ボタンについて



振動ボタン

吸引ボタン

タッピングボタン



マグネット充電ポート

使用方法

振動モード

「」を1.5秒間長押しすると、振動モードのオン/オフができます。

「」をクリックすると、8種類の振動モードが切り替わります。

吸引モード

「」を1.5秒長押しすると、吸引モードのオン/オフができます。

「」ボタンを短く押すと、10種類の吸引モードが切り替わります。

タッピングモード

「」を1.5秒長押しすると、タッピングモードのオン/オフができます。

「」ボタンを短く押すと、7種類のタッピングモードが切り替わります。

APP遠隔機能

スマホにBeYourLoverアプリをダウンロードしたら、おもちゃ本体と連携させます。(APPダウンロードは別紙参照)

スマホのBluetoothをONにして、おもちゃ本体の電源を入れてアプリを起動すれば、自動的に連携されます

LED表示状態

動作中	LED点灯
電池残量低下	LED点滅
充電中	LED点滅
充電完了	LED点灯

ご使用上の注意事項

この製品をご使用になる前に、必ずこの取扱説明書を最後までよくお読みいただき、使用上の注意事項、本製品の機能や使用方法などを十分に理解して、正しく安全にご使用いただくようお願いいたします。また、この取扱説明書は大切に保管していただき、今後の参照のためにお手元に置いておくことをおすすめします。●使用する前に製品をきれいに清潔し、水溶性ローションと合わせて使用してください。●長時間に使用しない場合はよく洗浄し、直射日光のあたる場所や高温、多湿になる場所を避けて保管してください。

充電について

●充電する際は必ず通常充電仕様のACアダプターと付属の充電ケーブルをご利用ください。急速充電仕様のものをご利用する場合は、製品の内蔵電池が劣化されたり、フル充電できなかつたりする恐れがあります。●充電時は接続部が濡れないようにご注意ください。●充電時間は12時間を超えないように注意してください。また充電する際は必ず目を離さず、注意監視してください。●充電しながらでのご利用はお止めください。

メンテナンス

- 本製品は防水レベルIPX6に達しておりますが、水中でのご使用、はなるべくお避け下さい。浸水すると故障する恐れがあります。
- 挿入部分は丸洗い可能ですが、吸引口はウェットティッシュで汚れを拭き取ってください。もしくは吸引口を水で洗浄後、綿棒などで吸引口の水をよく拭き取ってから、直射日光の当たらない所で保管してください。
- 初めてご利用するときや長期間ご使用しなかった時は必ず一度満充電にしてからご利用ください。

警告

- アダルトグッズのため、幼児の手の届かないところに保管してください。
- 本製品を使用中に皮膚アレルギーや不快感を感じた場合は、直ちに使用を中止し、必要に応じて医師の診察を受けてください。
- 故障が見つかったり、異常な動作を感じたら、直ちにご使用を中止し、電源を切ってください。

廃棄物処理

- 本製品はリチウムポリマー電池を内蔵しております。家庭ごみとして、処理しないでください。廃棄する場合は、電池を取り出してから各自治体の処理方法に従ってください。

使用前

在第一次使用前，請將產品充滿電。充電時間約為2.5小時，充滿電後LED長亮。

使用前請將乳頭、生殖器和其他部位的穿孔或首飾摘下並對產品進行清潔和消毒。如使用潤滑液，請用水溶性潤滑液充分潤滑產品和您的私處。

產品規格

產品名稱: Angela

產品型號: VX603A

材質: 矽膠, ABS

尺寸: 218*86.5*38.5mm

重量: 225g±5g

電池類型: 充電式聚合鋰電池

電池容量: 900mAh

額定電壓: 3.7V

額定電流: 900mA

充電時間: 2.5小時

使用時間: 50分鐘



振動模式: 8種類

吮吸模式: 8種類

拍打模式: 7種類

防水等級: IPX6

按鍵解析



磁吸充電孔

如何使用

振動模式

長按「」鍵1.5 秒，開啟/關閉震動模式。

按一下「」鍵可切換 8 種不同的震動模式。

吸吮模式

長按「」鍵1.5 秒，開啟/關閉吸吮模式。

點選「」鍵可切換 10 種不同的吸吮模式。

拍打模式

長按「」鍵1.5 秒，開啟/關閉拍打模式。

點選「」鍵切換 7種不同的拍打模式。

APP 遠端遙控功能

開啟手機藍牙功能，將產品連接到官方APP即可遠端控制。

(APP可掃描二維碼下載)

LED顯示狀態

工作中	LED滅燈
低電量	LED閃爍
充電中	LED閃爍
充滿電	LED長亮

使用注意事項

在使用本產品之前，請務必仔細閱讀本使用說明書的所有內容，充分理解使用注意事項、本產品的功能及使用方法，以便正確安全地使用本產品。另請妥善保管本使用說明書，以便日後參考。

- 使用前請將產品清潔乾淨，並搭配水溶性潤滑液使用。
- 長時間不使用時，請徹底清洗，避開直射陽光、高溫和高濕度的地方保存。

關於充電

- 充電時請務必使用標準充電規格的AC適配器和附帶的充電線。使用快速充電規格的充電器可能會導致內置電池劣化或無法完全充電。
- 充電時請注意不要讓接頭部分弄濕。
- 請注意充電時間不要超過12小時，充電時請勿離開並注意監控。

- 請勿在充電時使用本產品。

維護

本產品符合IPX6國際防水標準，可以防止各種角度的高壓水流。

浸水可能會導致故障。清洗後請擦乾水分並待其完全乾燥。

- 長時間不使用時，請避開潮濕和直射陽光的地方存放。
- 首次使用或長時間未使用後，請先將電池充滿電後再使用。

警告

- 由於是成人用品，請放置在兒童無法觸及的地方。
- 使用過程中如果感到皮膚過敏或不適，請立即停止使用，並在必要時諮詢醫生。
- 如果發現故障或異常情況，請立即停止使用並關閉電源。

廢棄物處理

- 本產品內置鋰聚合物電池，請勿作為家庭垃圾處理。廢棄時請取出電池，並按照各地方自治體的處理方法處理。





BeYourLover Official App
Download for free now!

BeYourLover公式アプリ
今すぐ無料ダウンロード!



BE YOUR LOVER

ビュアラバー

