



BE YOUR LOVER
ビーユアラバー



食人花
取扱説明書

Before Use

Please fully charge our product before the first use. The charging time is about 2 hours, after it's fully charged, the LED light will stay on.

Please remove piercings or jewelry in the nipple, genital, and other areas before use. Be sure to clean and disinfect the product before use. If you want to use a lubricant please adequately lubricate the product and your private parts with a water-based lubricant.

Product Specification

Product Name: Seductive Blossom

Product No.: VX736B

Material: Silicone, ABS

Size: 67*37*243mm

Weight: 364g±5g

Battery Type: Polymer lithium battery

Battery Capacity: 800mAh

Rated Voltage: 3.7V

Operating Current: 800mA

Charging Time: 2H

Working Time: 1H


Lick & Bite Modes: 10

Vibration Mode: 10

Suction Mode: 1 Type (3-level cycle)

Waterproof Rating: IPX6

Button Display



How to Use

Power (On/Off)

Press the button " " for 1s to turn on/off the power.

Lick & Bite Mode

Click the button " " to change 10 different lick & bite modes.

Press the button " " for 1s to turn off the lick & bite mode and the power.

Suction Mode

Click the button " " to turn on the suction mode, which will cycle through 3 levels automatically.

Press the button " " for 1s to turn off the suction mode.

Vibration Mode

Click the button " " to change 10 different vibration modes.

Press the button " " for 1s to turn off the vibration mode.

APP Connection Function

1.First, download the official app "BeYourLover".

(*Refer to the instruction sheet for download steps.)

2.Turn on Bluetooth on your phone.

3.Press and hold the product's power button to turn it on.

The device will automatically connect to the app. Once connected, you can control the product remotely via the app.

LED Display

Working	LED remains on
Low battery	LED flashes
Charging	LED flashes
Fully Charged	LED remains on

Usage Instructions

Before using this product, please read this instruction manual thoroughly and understand the usage precautions, product features, and methods to ensure correct and safe use. Additionally, keep this manual in a safe place for future reference.

- Clean the product thoroughly before use with a water-based lubricant.
- If not used for a long time, clean it well and store it away from direct sunlight, high temperatures, and high humidity.

Charging

- Always use a standard charging AC adapter and the included charging cable. The fast-charging adapter may cause the built-in battery to deteriorate or fail to charge fully.
- Make sure the connection part does not get wet during charging.
- Ensure the charging time does not exceed 12 hours and monitor the charging process closely.
- Do not use the product while charging.

Maintenance

This product complies with the international waterproof standard and can withstand high-pressure water flow from any angle. Submerging it in water may cause malfunction. Wipe off any moisture and dry it completely after rinsing.

- If not used for a long time, store it away from high humidity and direct sunlight.
- Before the first time or after a long period of non-use, make sure to charge it once fully.

Warning

- As this is an adult product, keep it out of reach of children.
- If you experience skin allergies or discomfort while using the product, stop using it immediately and consult a doctor if necessary.
- If you find any malfunction or abnormal behavior, stop using it immediately and turn off the power.

Disposal

- This product contains a lithium-polymer battery. Do not dispose of it as household waste. When disposing, remove the battery and follow the disposal methods prescribed by your local authorities.



214-250679



使用前

初めてお使いになる際は必ずフル充電を行ってからご使用ください。充電時間は約2時間で、フル充電するとLEDランプが点灯します。

本製品を使用する前には、乳首や性器などのピアスやアクセサリを取り外して、本製品を洗浄・消毒してからご使用ください。ローションを使用する場合は、水溶性ローションで製品とプライベートパーツをよく潤滑してください。

製品仕様

商品名: 食人花

製品型番: VX736B

材質: シリコン、ABS

サイズ: 67*37*243mm

重量: 364g±5g

バッテリータイプ: リチウムポリマー電池

バッテリー容量: 800mAh

動作電圧: 3.7V

動作電流: 800mA

充電時間: 2時間

使用時間: 1時間


舐め噛みモード: 10種類

振動モード: 10種類

吸引モード: 1種類 (3段階循環)

防水レベル: IPX6

ボタンについて



使用方法

電源スイッチ

「」ボタンを1秒間長押しすると、電源のオン/オフができます。

舐め噛みモード

「」ボタンを短押しすると、10種類の異なる舐め噛みモードが順に切り替わります。

「」ボタンを1秒間長押しすると、舐め噛みモードと電源がオフになります。

吸引モード

「」ボタンを短押しすると吸引モードが起動し、3段階の吸引レベルが自動で切り替わります。

「」ボタンを1秒間長押しすると、吸引モードがオフになります。

振動モード

「」ボタンを短押しすると、10種類の異なる振動モードが順に切り替わります。

「」ボタンを1秒間長押しすると、振動モードがオフになります。

APP連携機能

1.まず、公式アプリ「BeYourLover」をダウンロードしてください。

(※ダウンロード方法は別紙参照)。

2.次に、スマートフォンのBluetooth機能をオンにします。

3.製品の電源ボタンを長押しして起動すると、自動的にアプリと接続されます。

接続が完了すると、アプリからの遠隔操作が可能になります。

LED表示状態

動作中	LED点灯
電池残量低下	LED明滅
充電中	LED明滅
充電完了	LED点灯

ご使用上の注意事項

この製品をご使用になる前に、必ずこの取扱説明書を最後までよくお読みいただき、使用上の注意事項、本製品の機能や使用方法などを十分に理解して、正しく安全にご使用いただくようお願いいたします。また、この取扱説明書は大切に保管していただき、今後の参照のためにお手元に置いておくことをおすすめします。●使用する前に製品をきれいに清潔し、水溶性ローションと合わせて使用してください。●長時間に使用しない場合はよく洗浄し、直射日光のあたる場所や高温、多湿になる場所を避けて保管してください。

充電について

●充電する際は必ず通常充電仕様のACアダプターと付属の充電ケーブルをご利用ください。急速充電仕様のものをご利用する場合は、製品の内蔵電池が劣化されたり、フル充電できなかつたりする恐れがあります。●充電時は接続部が濡れないようにご注意ください。●充電時間は12時間を超えないように注意してください。また充電する際は必ず目を離さず、注意監視してください。●充電しながらでのご利用はお止めください。

メンテナンス

本製品は国際防水規格に準拠しており、あらゆる角度で高圧水の流れを防ぐことができます。●長時間使用しない場合は、多湿になる場所を避けて、直射日光の当たらない所で保管してください。●初めてご利用するときや長期間ご使用しなかった時は必ず一度満充電にしてからご利用ください。

警告

●アダルトグッズのため、幼児の手の届かないところに保管してください。●本製品を使用中に皮膚アレルギーや不快感を感じた場合は、直ちに使用を中止し、必要に応じて医師の診察を受けてください。●故障が見つかったり、異常な動作を感じたら、直ちにご使用を中止し、電源を切ってください。

廃棄物処理

●本製品はリチウムポリマー電池を内蔵しております。家庭ごみとして、処理しないでください。廃棄する場合は、電池を取り出してから各自治体の処理方法に従ってください。



214-250679



使用前

在第一次使用前，請將產品充滿電。充電時間約為2小時，充滿電後LED長亮。

使用前請將乳頭、生殖器和其他部位的穿孔或首飾摘下並對產品進行清潔和消毒。如使用潤滑液，請用水溶性潤滑液充分潤滑產品和您的私處。

產品規格

產品名稱：食人花

產品型號：VX736B

材質：矽膠、ABS

尺寸：67*37*243mm

重量：364g±5g

電池類型：充電式聚合鋰電池

電池容量：800mAh

工作電壓：3.7V

工作電流：800mA

充電時間：2小時

使用時間：1小時



舔咬模式：10種

震動模式：10種

吸氣模式：1 種類（3 檔循環）

防水等級：IPX6

按鍵解析



按鍵解析

電源開關

長按「」鍵1秒，開啟/關閉電源。

舔咬模式

短按「」鍵切換10種不同的舔咬模式。

長按「」鍵1秒，關閉舔咬模式及電源。

吸氣模式

短按「」鍵，開啟吸氣模式，並自動循環三檔。

長按「」鍵1秒，關閉吸氣模式。

振動模式

短按「」鍵切換10種不同的振動模式。

長按「」鍵1秒，關閉振動模式。

APP連接功能

- 1.請先下載官方APP「BeYourLover」。
(※下載方式請參閱附頁)
- 2.開啟手機的藍牙功能。
- 3.長按產品電源鍵開機後，將自動連接至APP。
連接成功後，即可透過APP進行遠端操作。

LED顯示狀態

工作中	LED長亮
低電量	LED閃爍
充電中	LED閃爍
充滿電	LED長亮

使用注意事項

在使用本產品之前，請務必仔細閱讀本使用說明書的所有內容，充分理解使用注意事項、本產品的功能及使用方法，以便正確安全地使用本產品。另請妥善保管本使用說明書，以便日後參考。

- 使用前請將產品清潔乾淨，並搭配水溶性潤滑液使用。
- 長時間不使用時，請徹底清洗，避開直射陽光、高溫和高濕度的地方保存。

關於充電

- 充電時請務必使用標準充電規格的AC適配器和附帶的充電線。使用快速充電規格的充電器可能會導致內置電池劣化或無法完全充電。
- 充電時請注意不要讓接頭部分弄濕。
- 請注意充電時間不要超過12小時，充電時請勿離開並注意監控。
- 請勿在充電時使用本產品。

維護

本產品符合國際防水標準，可以防止各種角度的高壓水流。浸水可能會導致故障。清洗後請擦乾水分並待其完全乾燥。

- 長時間不使用時，請避開潮濕和直射陽光的地方存放。
- 首次使用或長時間未使用後，請先將電池充滿電後再使用。

警告

- 由於是成人用品，請放置在兒童無法觸及的地方。
- 使用過程中如果感到皮膚過敏或不適，請立即停止使用，並在必要時諮詢醫生。
- 如果發現故障或異常情況，請立即停止使用並關閉電源。

廢棄物處理

- 本產品內置鋰聚合物電池，請勿作為家庭垃圾處理。廢棄時請取出電池，並按照各地方自治體的處理方法處理。



214-250679





BeYourLover Official App
Download for free now!

BeYourLover公式アプリ
今すぐ無料ダウンロード!



BE YOUR LOVER

ビュアラバー

